LEGACY INTERIOR LOW SHEEN

TDS01-880

DESCRIPTION

An acrylic based interior Wall paint. Formulated to dry to an attractive low sheen finish over correctly prepared drywall over coated with Trueprep Drywall Sealer

TYPICAL USES

Interior walls:
- Block and brickwork
- Concrete and plaster
- Fibre and particle board
- Fibre cement
- Paper faced plasterboard
- Timber
- Wallpaper
- Wallboards

ENVIRONMENT

Interior

PERFORMANCE

Excellent cutting and rolling properties to provide good coverage in all off white and pastel colours. Good burnish and stain resistance

LIMITATIONS

Do not apply if the air and surface temperature during application and drying is likely to fall below 10ºC. Not recommended for interior wet or high humidity areas such as bathrooms, laundries and kitchens (if poorly ventilated). Use Aquatec WB Enamel or Aquatec PU.

TECHNICAL DATA

Resin: Acrylic
Solvent: Water
Appearance: White
Colour: White and Pastel
Primer: See over.
Durability: Good
Pack Size: 10L
VOC: <40g/litre
Vol Solids: 38 percent
Touch Dry: 60 minutes @20°C
Recoat Time: 2 Hours @20°C
Number of Coats: 2 to 3
Theoretical Coverage: 10 m²/litre/coat
Wet Film Thickness: 100 microns
Dry Film Thickness: 38 microns

AVAILABLE FINISHES @60°C

Sheen

Low Sheen 7 -9%

SPREAD RATE

First Coat: 10 - m²/litre/coat
Second Coat: 12 - m²/litre/coat
Practical spreading rates will vary depending on such factors as application method, ambient conditions and surface porosity and roughness.

PRODUCT CODES

01-880

PRIMERS AND UNDERCOATS

Substrate	Primer / Undercoat	Technical Data Sheet
Plasterboard	TRUEPREP EASYSAND	See TDS05-158
Plasterboard	TRUEPREP DRYWALL SEALER	See TDS05-675
Plasterboard	TRUEPREP MULTIPURPOSE ALKYD PRIMER UNDERCOAT	See TDS55-550URO
Plasterboard	TRUEPREP MULTIPRIME	See TDS05-100

cotec

SURFACE PREPARATION

Plasterboard-New Unpainted
All surfaces must be clean, dirt, grease and any other surface contaminant. wipe with a damp cloth to remove dust. Avoid scuffing the paper surface substrate.

Inspect the substrate prior to applying any coating system to ensure there is no contamination present and no surface defects exists. If there is either contaminants or defects are present, rectification process is required prior to any coating is applied.

Allow to apply first coat of primer/ sealer and allow to fully cure.

If required, apply appropriate flexible paintable sealant, to gaps between skirting boards, framing and scotia's and fill any minor defects using TRUEPREP STOP-IT.

Plasterboard-Previously Painted Good
If any areas of moss or mould infestation exist, then treat them with a form of moss & mould killer solution. In area that has signs of mould infestation, it can be removed with a wipe of concentrated moss and mould killer solution on a damp cloth.

Liquid sugar soap or similar cleaner is a good method for cleaning all contaminates of the existing substrate. The surface will need to be thoroughly cleaned down to remove any residue left.

Thoroughly scrape and sand to remove all loose and flaking paint. Sand all flaking paint to a feathered edge. This will help provide a good key for painting.

Fill all cracks or holes with Trueprep STOP-IT filler, applied according to the manufacturer's instructions. Once dry sand smooth.

Seal all repaired areas and any areas of bare substrate with the manufactures recommended sealer/ undercoat.

If there are any signs of water-staining that is visible on the walls or ceilings. We would recommend to seal that entire surface with TRUEPREP MULTIPURPOSE ALKYD PRIMER UNDERCOAT which has excellent stain blocking properties. Refer to TDS for all manufactures recommendation.

MIXING INSTRUCTIONS

Stir thoroughly before use.

THINNING

Maximum 5% Cotec Retarder or Cotec Spray thinner for spray application.

ENVIRONMENTAL

This formulation uses the latest technology with low toxicity, ensuring environmental issues are not compromised. DO NOT POUR paint or wash down storm water or water courses. ALWAYS dispose of in accordance with local Government regulations. Soak up spills with absorbent material and dispose of properly. If spraying use suitable respiratory protection. Refer to the MATERIAL SAFETY DATA SHEET

COATING TECHNOLOGIES LIMITED
10 Andromeda Crescent, East Tamaki, Auckland 2013 Ph +64 9 837 0897 www.cotec.co.nz

Technical information given verbally or in writing is based on knowledge and research, given in good faith and believed to be reliable, but no guarantee of accuracy is made or implied. Since methods and conditions of use are beyond our control, all merchandise is sold and received subject to the condition that our liability whether express or implied for any defect in quality, or for any lack of fitness for the specified use thereof, is limited to the return of the purchase price if written claim is made within 14 days from the date of delivery. It is recommended that the user makes his or her own tests to determine the suitability of the product for his own requirements. Freedom from patent restrictions is not implied.